

MIXING INSTRUCTIONS:

LAST PATCH™ -GEL_(KG)

Part “A” may be tinted with Touchstone™ colorants or powdered tints before Part “B” is added. Mix thoroughly for 30 seconds. This sample with the accelerator level included will set up in 10 or 15 minutes. It will become a stiff rubbery product at a half hour. The Last Patch™ will become harder and harder over several days.

For small hole filling on polished surfaces, simply razor blade flush before the Last Patch™ Gel sets up. It will cure to a gloss finish.

For honed surfaces dry grinding is recommended after 3 or 4 hours unless accelerator is used. (Dry grinding creates a heating effect which kicks over the product faster).

Additional granite dust or granules may be added to create variation for the over-fill and grind technique.

An accelerator is available for even faster set-up and hardening times. Please ask for Last Patch™ accelerator when ordering.